

# Infrared Detectors

Covering a broad spectral range in the infrared region



HAMAMATSU PHOTONICS K.K.

# Infrared detectors

Infrared detectors are widely used in diverse field including measurement, analysis, industry, communication, agriculture, medicine, physical and chemical science, astronomy and space. Based on long experience involving photonic technology, HAMAMATSU provides a wide variety of infrared detectors in order to meet a large range of application needs. In addition to the standard devices listed in this catalog, custom devices are also available on request. Please feel free to contact the nearest sales office in your area.



# Contents **→**

- InGaAs PIN photodiodes ..... 1
- PbS/PbSe photoconductive detectors



InAs/InAsSb/InSb
photovoltaic detectors,
InSb photoconductive
detectors

--- 11

MCT (HgCdTe)
photoconductive/
photovoltaic detectors14
Thermopile detectors
(Si thermal detectors)17
Two-color detectors18

Photon drag detector20
Accessories for infrared detectors21
■ Description of terms27


# Infrared detectors

### HAMAMATSU infrared detectors

Product name	Spectral response range (µm)	Features	Paga
Froduct name	0 1 2 3	reatures	Page
	0.5 1.7	Short wavelength enhanced type     Can detect light from 0.5 µm	1
	0.9 1.7	Standard type     High-speed response, high sensitivity, low dark current     Available various types of photosensitive areas, arrays and packages	1, 2
InGaAs PIN photodiodes	0.9 1.9	<ul> <li>For optical measurement around 1.7 μm</li> <li>Available TE-cooled type</li> </ul>	3
	0.9 2.1	For optical measurement in the band of water content absorption (1.9 µm)  Available TE-cooled type	3
	0.9 2.6	For NIR spectroscopy     Available TE-cooled type	4
InGaAs image sensors	0.9 2.55	Types for spectrophotometry and WDM monitor, and high-speed type available	6 to 8

			Spectral response range	(µm)		D
	Pro	oduct name	0 5 10 15 20	25	Features	Page
Discontinued	PbS photocor	nductive detectors	1 3.2		Photoconductive detectors whose resistance decreases with the input of infrared light     Can be used at room temperatures in a wide range of applications such as radiation thermometers and flame monitors	9, 10
Discontinued	PbSe photoco	onductive detectors	1 5.2	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Detects wavelengths up to 5.2 µm     Offers higher response speed at room temperatures compared to other detectors used in the same wavelength range. Suitable for a wide range of applications such as gas analyzers.	9, 10
	InAs photovo	Itaic detectors	1 3.8		Covers a spectral response range close to PbS but offers higher response speed	11
-	InAsSb photo	voltaic detectors	1 8.3	0 0 0 0 0 0 0 0 0 0 0 0	Infrared detectors in the 5 µm or 8 µm spectral band, with high sensitivity and high reliability     High-speed response	11
-	InSb photovol	Itaic detectors	1 5.5		• High-speed and high sensitivity in so-called atmospheric window (3 to 5 µm)	12
	InSb photoco	nductive detectors	1 6.7		Detects wavelengths up to around 6.5 µm, with high sensitivity over long periods by thermoelectric cooling	12
Discontinued	MCT (HgCdTedetectors	e) photoconductive	1	25	Various types with different spectral response range are provided by changing the HgTe and CdTe composition ratio.     High sensitivity photoconductive detectors whose resistance decreases with the input of infrared light     Available with TE-cooled type and cryogenic dewar	14, 15
Discontinued	MCT (HgCdTe	) photovoltaic detectors	1 13.5		High-speed response and low noise	15
-	Thermopile de	etectors	1	25	Sensors that generate thermoelectromotive force in proportion to the energy level of incident infrared light	17
Discontinued		Si + PbS	0.2 3	- - - - - - -		
Discontinued	Two-color	Si + PbSe	0.2 4.85		Wide spectral response range from UV to IR	10.10
	detectors	Si + InGaAs	0.32 2.55	- - - - - - -	Uses two detectors with different spectral response ranges, mounted one over the other along the same optical axis	18, 19
		InGaAs + InGaAs	0.9 2.55			
	Photon drag c	detector	10	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	High-speed detector with high sensitivity in 10 µm band (for CO <sub>2</sub> laser detection)     Room temperature operation with high-speed response	20

For detailed information on the products listed in this catalog, see their datasheets that are available from our website www.hamamatsu.com



When using infrared detectors, the following points should be taken into consideration for making a device selection.

### Spectral response

As can be seen from the figure above, HAMAMATSU provides a variety of infrared detectors with different spectral response characteristics. It should be noted that cooling a detector element may affect its spectral response. For InGaAs, InAs, InSb and InAsSb detectors, the spectral response shifts to the shorter wavelength side; in contrast, for PbS, PbSe and MCT detectors it shifts to the longer wavelength side.

### Response speed

Various detectors are available with different response speeds. It should be noted that the response speeds of the PbS and PbSe detectors become worse with cooling.

### Photosensitive area and number of elements

HAMAMATSU photosensors are available in a wide range of photosensitive area sizes. Also available are multi-element detector arrays optimized for high-speed multichannel spectrophotometry.


### Cooling

Besides easy-to-use photosensors designed for room temperature, HAMAMATSU provides various types of sensors that are cooled with thermoelectric coolers, cryogenic dewars (for liquid nitrogen cooling).

### Object temperature

When selecting a detector in accordance with the temperature of an object, it is necessary to consider the distribution of the energy (the wavelength dependency of the energy) radiated from the object. When the temperature of the object is changed, the distribution of the radiating energy is given by the law of black body radiation (Planck's law), as shown in the figure at the right-hand side. The following relationship is established by the peak sensitivity wavelength  $\lambda p$  ( $\mu m$ ) and the absolute temperature T (K).  $\lambda p \cdot T = 2897.9$ 

### Law of black body radiation (Planck's law)



KIRDB0014EB

# InGaAs PIN photodiodes

### Short wavelength enhanced type

(Typ. Ta=25  $^{\circ}$ C, unless otherwise noted)

Type no.	Cooling	Photosensitive area (mm)	Spectral response range λ (μm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc V <sub>R</sub> =1 V (MHz)	Package	Photo	Option (sold separately)
G10899-003K		φ0.3			300		п	
G10899-005K		φ0.5			150	TO-18		
G10899-01K	Non-cooled	ф1	0.5 to 1.7	1.55 45	45	10	Ш	C4159-03 (P.25)
G10899-02K		ф2			10		3	
G10899-03K		ф3			5	TO-5		

### Standard type

### ■ Metal package

Various photosensitive area sizes are available.

(Typ. Ta=25 °C, unless otherwise noted)

Type no.	Cooling	Photosensitive area (mm)	Spectral response range λ (μm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc (MHz)	Package	Photo	Option (sold separately)
G12180-003A		ф0.3			600 (VR=5 V)			
G12180-005A		ф0.5			200 (VR=5 V)	TO-18		
G12180-010A		φ1			60 (VR=5 V)	-		
G12180-020A		ф2			13 (V <sub>R</sub> =1 V)		8	
G12180-030A		ф3			7 (VR=1 V)	- TO-5		
G12180-050A	Non-cooled	ф5	0.9 to 1.7		3 (VR=1 V)	TO-8	7	C4159-03 (P.25)
G8370-81*		ф1			35 (V <sub>R</sub> =1 V)	TO-18 - TO-5		
G8370-82*		ф2			4 (V <sub>R</sub> =1 V)		3	
G8370-83*		ф3		1.55	2 (V <sub>R</sub> =1 V)			
G8370-85*		ф5			0.6 (V <sub>R</sub> =1 V)	TO-8		
NEW G12180-110A		ф1			40 (VR=1 V)			C4159-03 (P.25)
NEW G12180-120A	One-stage	ф2			13 (VR=1 V)			
NEW G12180-130A	TE-cooled (Td=-10 °C)	ф3	0.9 to 1.67	-	7 (VR=1 V)			A3179 (P.23) C1103-04 (P.22)
NEW G12180-150A		ф5			3 (V <sub>R</sub> =1 V)	TO 0		
NEW G12180-210A		ф1			40 (V <sub>R</sub> =1 V)	- TO-8		
NEW G12180-220A	Two-stage	ф2	0.0.4.05		13 (V <sub>R</sub> =1 V)			C4159-03 (P.25)
NEW G12180-230A	TE-cooled (Td=-20 °C)	ф3	0.9 to 1.65		7 (V <sub>R</sub> =1 V)		A3179-01 ( C1103-04 (	A3179-01 (P.23) C1103-04 (P.22)
NEW G12180-250A		ф5			3 (V <sub>R</sub> =1 V)	1	Ŧ I	
G6854-01	Non-cooled	ф0.08	0.9 to 1.7		2000 (VR=5 V)	TO-18 with CD lens	<b>S</b>	

<sup>\*</sup> Low PDL (polarization dependent loss) type

### ■ Ceramic package

(Typ. Ta=25 °C)

Type no.	Photosensitive area	Spectral response range λ (μm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc V <sub>R</sub> =5 V (MHz)	Package	Photo
G11193-02R	φ0.2			1000	Surface mount type	
G11193-03R	ф0.3	0.9 to 1.7	1.55	500	ceramic	
G8370-10	φ10			0.1 (V <sub>R</sub> =0 V)	Ceramic	4

### ■ Surface mount type


(Typ. Ta=25 °C)

Type no.	Photosensitive area (mm)	Spectral response range λ (μm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc VR=5 V (MHz)	Package	Photo	Туре
G8941-01	ф1	0.9 to 1.7		35		4	
G8941-02	φ0.5	0.9 to 1.7	1.55	200	Ceramic (non-sealed)		Front- illuminated type
G8941-03	φ0.3	0.9 to 1.7	1.55	400			
G11777-003P	ψυ.3	0.9 to 1.7		500	Plastic	C	СОВ


### Spectral response

### G10899 series, etc.


KIRDB0444EE



### G12180 series



### G11193 series, G8370-10, etc.



KIRDB0284EC

## **6** Long wavelength type

### Peak sensitivity wavelength: 1.75 μm

These are suitable for optical measurement around 1.7  $\mu m.$ 

(Typ. Ta=25 °C, unless otherwise noted)

Type no.	Cooling	Photosensitive area (mm)	Spectral response range $\lambda$ (µm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc VR=0 V (MHz)	Package	Photo	Option (sold separately)
G12181-003K		ф0.3			90			
G12181-005K		ф0.5			35	35 TO-18	9	
G12181-010K	Non-cooled	ф1	0.9 to 1.9		10		-	C4159-03 (P.25)
G12181-020K		ф2			2.5	TO 5	9	(20)
G12181-030K		ф3			1.5	TO-5		
G12181-103K		ф0.3			140	TO-8		C4159-03 (P.25) A3179 (P.23) C1103-04 (P.22)
G12181-105K	0	ф0.5			50			
G12181-110K	One-stage TE-cooled	ф1	0.9 to 1.87	1.75	16			
G12181-120K	(Td=-10 °C)	ф2			3.5			
G12181-130K		ф3			1.8			
G12181-203K		ф0.3			150			
G12181-205K		φ0.5			53			04450 00 (D05)
G12181-210K	Two-stage TE-cooled	φ1	0.9 to 1.85		17 TO-8	TO-8		C4159-03 (P.25) A3179-01 (P.23)
G12181-220K	(Td=-20 °C)	ф2			3.7			C1103-04 (P.22)
G12181-230K		ф3			1.9			

### Note: The Peak sensitivity wavelength: 1.95 μm

These are suitable for optical measurement in the 1.9  $\mu m$  band such as water absorption.

(Typ. Ta=25 °C, unless otherwise noted)

	(Typ. Ta=25 °C, unless	otherwise noted)									
Type no.	Cooling	Photosensitive area (mm)	Spectral response range $\lambda$ (µm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc VR=0 V (MHz)	Package	Photo	Option (sold separately)			
G12182-003K		ф0.3			90						
G12182-005K		φ0.5	35	TO-18	<u> </u>						
G12182-010K	Non-cooled	φ1	0.9 to 2.1		10		494	C4159-03 (P.25)			
G12182-020K		φ2			2.5	TO-5	9				
G12182-030K		ф3			1.5	10-5					
G12182-103K		ф0.3					140	)			
G12182-105K	One stone	ф0.5			50	TO-8		C4159-03 (P.25) A3179 (P.23) C1103-04 (P.22)			
G12182-110K	One-stage TE-cooled (Td=-10 °C)	ф1	φ1 0.9 to 2.07 1.95	1.95	16						
G12182-120K	(1d=-10 °C)	ф2			3.5						
G12182-130K		ф3			1.8						
G12182-203K		ф0.3			150		0.000				
G12182-205K	Tura ata sa	ф0.5			53			C41E0 02 (D2E)			
G12182-210K	Two-stage TE-cooled	ф1	0.9 to 2.05		17			C4159-03 (P.25) A3179-01 (P.23) C1103-04 (P.22)			
G12182-220K	(Td=-20 °C)	ф2			3.7						
G12182-230K		ф3			1.9						

### Peak sensitivity wavelength: 2.3 μm


These are suitable for use in NIR (near infrared) spectroscopy.

(Typ. Ta=25 °C, unless otherwise noted)


Type no.	Cooling	Photosensitive area (mm)	Spectral response range $\lambda$ (µm)	Peak sensitivity wavelength λp (μm)	Cutoff frequency fc VR=0 V (MHz)	Package	Photo	Option (sold separately)	
G12183-003K		ф0.3			50				
G12183-005K		φ0.5	20	TO-18					
G12183-010K	Non-cooled	Non-cooled	ф1	0.9 to 2.6		6			C4159-03 (P.25)
G12183-020K		ф2			1.5	TO-5	9		
G12183-030K		ф3			0.8	10-5			
G12183-103K	One-stage TE-cooled (Td=-10 °C)		ф0.3			70			
G12183-105K		φ0.5			25			C41E0 02 (D2E)	
G12183-110K		TE-cooled	ф1	0.9 to 2.57	2.3	7	TO-8		C4159-03 (P.25) A3179 (P.23) C1103-04 (P.22)
G12183-120K			ф2			2			
G12183-130K		ф3			0.9				
G12183-203K		ф0.3			75				
G12183-205K		φ0.5			28			0.4450.00 (D05)	
G12183-210K	Two-stage TE-cooled (Td=-20 °C)	ф1	0.9 to 2.55		8 TO-8	TO-8		C4159-03 (P.25) A3179-01 (P.23) C1103-04 (P.22)	
G12183-220K		ф2			2.3			C1103-04 (F.22)	
G12183-230K		ф3			1				

### Spectral response


### G12181 series



### G12182 series



### G12183 series



KIRDB0491EC


### for Infrared detector modules with preamp

These modules consist of the InGaAs PIN photodiode assembled with matched preamplifier, and operate by connecting a DC power supply. (Typ.)

Type no.	Detector	Cooling	Photosensitive area (mm)	Measurement condition Element temperature (°C)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Photo
G6121	G8370-05	Non-cooled	ф5	25	1.70	1.55	
NEW C12485-210	G12182-210K				2.05	1.95	
NEW C12486-210	G12183-210K	TE-cooled	φ1	-15	2.56	2.30	
NEW C12483-250	G12180-250A		ф5		1.66	1.55	
G7754-01	G12183-010 (chip)	I in the interest of	ф1	100	0.4	2.0	
G7754-03	G12183-030 (chip)	Liquid nitrogen	ф3	-196	2.4	2.0	

Note: Supplied with a power supply cable

### Spectral response



KIRDB0369EE

### f Image sensors, photodiode arrays

### ■ InGaAs linear image sensors for spectrophotometry

One-stage TE-cooled types can be cooled down to -10 °C and cover a spectral range from 0.9 to 1.67  $\mu m.$ 

Type no.	Cooling	Pixel pitch (µm)	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G9211-256S		50	256	10.0 0.05	2.8 × 0.25 0.9 to 1.67 2.8 × 0.5	1% max.		
G9212-512S	One-stage	25	512	12.6 X 0.25				C8061-01
G9213-256S	TE-cooled (Td=-10 °C)	50	256	12.8 × 0.5				
G9214-512S		25	512					

Output can be obtained from all pixels since there are no defective pixels. Suitable for precision measurement.

Type no.	Cooling	Pixel pitch	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G9201-256S	One-stage	50	256	12.8 × 0.25	0.9 to 1.67		00	C00C1 01
G9202-512S	TE-cooled (Td=-10 °C)	25	512	12.0 X 0.25	0.0 to 1.07		•	C8061-01  C8061-01
G9203-256D	Non-cooled	50	256		0.9 to 1.7			_
G9203-256S	One-stage TE-cooled (Td=-10 °C)	50	256	10.0.05	0.9 to 1.67	0		C8061-01
G9204-512D	Non-cooled	25	512	12.8 × 0.5	0.9 to 1.7			_
G9204-512S	One-stage TE-cooled (Td=-10 °C)	25	512		0.9 to 1.67			C8061-01

Two-stage TE-cooled types can be cooled down to -20 °C, which make them suitable for measuring longer wavelengths from 0.9 to  $2.55 \, \mu m$ .

Type no.	Cooling	Pixel pitch	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G9205-256W		50	256		0.9 to 1.85	5% max.		
G9205-512W		25	25 512		0.5 to 1.05	4% max.		
G9206-256W		50	256		0.9 to 2.05	F0/ many		
G9206-02	Two-stage	50	230	12.8 × 0.25	0.9 to 2.15	5% max.	0 0	00000 01
G9206-512W	TE-cooled (Td=-20 °C)	25	512	12.8 × 0.25	0.9 to 2.15	4% max.	••	C8062-01
G9207-256W		EQ.	256		0.9 to 2.25	F0/ many		
G9208-256W		50	50 256		0.9 to 2.55	5% max.		
G9208-512W		25	512		0.9 to 2.55	4% max.		

### ■ High-speed type InGaAs linear image sensors

These are high-speed linear image sensors suitable for industrial and measurement equipment.

Type no.	Cooling	Pixel pitch	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G9494-256D	- Non-cooled	50	256	12.8 × 0.05	0.0+0.17	19/ may	1-1	- C10820
G9494-512D		25	512	12.8 × 0.025	0.9 to 1.7	1% max.		C 10020

These are 1024 pixels, high-speed NIR linear image sensors designed for applications such as a foreigh object screening and medical diagnostic equipment where a multichannel high-speed line rate is required.

Type no.	Cooling	Pixel pitch	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G10768-1024D	Non-cooled	25	1024	25.6 × 0.1	0.9 to 1.7	1% max.		C10854
G10768-1024DB	Non-cooled	25	1024	25.6 × 0.025	0.9 (0 1.7	170 IIIdX.		C 10654


### ■ Back-illuminated type InGaAs linear image sensor

These linear image sensors use a back-illuminated type InGaAs photodiode array that is bump-connected to a CMOS-ROIC with a single output terminal.


Type no.	Cooling	Pixel pitch	Number of pixels	Photosensitive area (mm × mm)	Spectral response range $\lambda$ (µm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G11135-256DD		50	256	12.8 × 0.05				C11514
G11135-512DE		25	512	12.8 × 0.025				C11014
G11620-128DA	Non-cooled	EQ.	128	6.4 × 0.5	0.95 to 1.7			
G11620-256DA	Non-cooled	50	256	12.8 × 0.5	0.95 to 1.7	10/		011510
G11620-256DF		0.5	256	6.4 × 0.5		1% max.		C11513
G11620-512DA		25	512	12.8 × 0.5	1			
G11620-256SA	One-stage	50	256	12.8 × 0.5			0 0	
G11620-512SA	TE-cooled (Td=-10 °C) 25	512	12.8 × 0.5	0.95 to 1.67			_	

### Spectral response

G9201 to G9208 series, etc.



### G10768 series



KMIRB0068EC

KMIRB0042EB

### ■ InGaAs area image sensors

Here is a hybrid structure consisting of a CMOS readout circuit (ROIC: readout integrated circuit) and back-illuminated InGaAs photodiode array.


Type no.	Cooling	Pixel pitch (µm)	Number of pixels	Photosensitive area (mm × mm)	Spectral response range λ (μm)	Defective pixels	Photo	Applicable driver circuit (sold separately)
G11097-0606S	One-stage TE-cooled		64 × 64	3.2 × 3.2	0.95 to 1.7			C11512
G11097-0707S	(Td=25 °C)	50	128 × 128	6.4 × 6.4	0.99 to 1.7	1% max.	0.0	C11512-01
G12460-0606S	One-stage TE-cooled (Td=0 °C)		64 × 64	3.2 × 3.2	1.12 to 1.9			C11512
G12242-0707W	Two-stage	20	128 × 128	2.56 × 2.56	0.95 to 1.7			C11512-02
NEW G12242-0909W	TE-cooled (Td=15 °C)	20	640 × 512	12.8 × 10.24	0.99 (0 1.7	0.37% max.		C12376

### ■ InGaAs photodiode arrays


- meante pho	todiodo arrayo				(Typ. Ta=25 °C)
Type no.	Photosensitive area (mm)	Spectral response range λ (μm)	Peak sensitivity wavelength λρ (μm)	Package	Photo
G6849-01	φ1 (Quadrant element)			TO-5	
G6849	φ2 (Quadrant element)			10-5	
G7150-16	0.45 × 1.0 (16-element)				
G7151-16	0.08 × 0.2 (16-element)	0.04- 4.7	455		
G12430-016D	0.45 × 1.0 (16-element)	0.9 to 1.7	1.55	Ceramic	
G12430-032D	0.2 × 1.0 (32-element)				
G12430-046D	0.2 × 1.0 (46-element)				
G8909-01	φ0.08 (40-element)			Ceramic (Non-sealed)	-

### Spectral response


### InGaAs area image sensors



### G12460-0606S



### InGaAs photodiode arrays



KMIRB0051EB KMIRB0078EA

# PbS/PbSe photoconductive detectors

**Discontinued** 


PbS and PbSe detectors are photoconductive sensors whose resistance decreases with the input of infrared light. PbS has a spectral response range from 1 to 3.2 µm, while the PbSe has a wider spectral range from 1.5 to 5.2 µm.

### PbS photoconductive detectors

PbS photoconductive detectors are infrared sensors having a spectral response range from 1 to 3.2 µm. These sensors can be used at room temperature in a wide range of applications such as radiation thermometers and flame monitors.

	Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
Discontinued	P9217		1 × 5					
Discontinued	P9217-02		2 × 2	2.9		TO-5	•	
Discontinued	P9217-03	Non-cooled	3 × 3		2.2		404	C3757-02 (P.26)
Discontinued	P9217-04		4 × 5			TO-8		
Discontinued	P2532-01	One-stage TE-cooled (Td=-10 °C)	4 × 5	3.1	2.4	TO-8		C3757-02 (P.26) A3179 (P.23) C1103-04 (P.22)
Discontinued	P2682-01	Two-stage TE-cooled (Td=-20 °C)	4 X 5	3.2	2.5	10-8		C3757-02 (P.26) A3179-01 (P.23) C1103-04 (P.22)

### Spectral response




### PbSe photoconductive detectors


PbSe photoconductive detectors are infrared sensors having a spectral response range from 1.5 to 5.2 µm. These sensors deliver high sensitivity and high-speed response at room temperatures. Cooled types are also available with a higher S/N making them widely used in precision photometry such as analytical and measuring instrument. (Typ.)

	Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λρ (μm)	Rise time max. (µs)	Package	Photo	Option (sold separately)
Discontinued	P9696-02		2 × 2	4.8	4.0			9	
Discontinued	P9696-03	- Non-cooled	3 × 3	4.0	4.0	10	TO-5	M	C3757-02
Discontinued	P3207-08*		2 × 2	4.35	4.25	10			(P.26)
Discontinued	P9696-102	One-stage	2 × 2		4.1				C3757-02 (P.26)
Discontinued	P9696-103	TE-cooled (Td=-10 °C) Two-stage TE-cooled	3 × 3	5.1	4.1	20	TO-8		A3179 (P.23) C1103-04 (P.22)
Discontinued	P9696-202		2 × 2	5.2	4.0	20	10-8	9	C3757-02 (P.26)
Discontinued	P9696-203	(Td=-20 °C)	3 × 3		4.2				A3179-01 (P.23) C1103-04 (P.22)

### P9696 series







KIRDB0540EB

### f Infrared detector modules with preamp


These modules consist of an infrared detector assembled with a matched preamplifier, and operate by connecting a DC power supply.

KIRDB0342EF

			Photosensitive		Measurement condition	Cutoff wavelength	Peak sensitivity wavelength		
	Type no.	Detector	area (mm)	Cooling	Element temperature (°C)	λc (μm)	λp (μm)	Photo	
Discontinued	d P4245	PbSe (P9696-03)	3 × 3	Non-cooled	25	4.8	4.0		
Discontinued	P4638	PbS (P2682-01)	4 × 5	TE appled	-15	3.1	2.4		
Discontinued	P4639	PbSe (P9696-203)	3 × 3	TE-cooled	-10	5.0	4.1		

Note: Supplied with a power supply cable

### Spectral response



# InAs/InAsSb/InSb photovoltaic detectors, InSb photoconductive detectors

InAs photovoltaic detectors are capable of detecting infrared light up to approx. 3.5 µm. InSb photovoltaic detector can sense infrared light up to approx. 5.5 µm, and InSb photoconductive detectors infrared light up to approx. 6 µm. InAsSb photovoltaic detectors also delivers high sensitivity in the 5 µm or 8 µm band. InSb photoconductive detectors are available in multi-element arrays (custom-made product). InAs and InSb photovoltaic detectors cover a spectral response range equivalent to PbS and PbSe photoconductive detectors, respectively, and feature higher response speed and better S/N.

### InAs photovoltaic detectors

InAs photovoltaic detectors are high-speed, low-noise infrared detectors capable of detecting infrared light up to approx. 3.5 µm. (Tvn.)

·	o .				o .		· (Typ.)
Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength (µm)	Package	Photo	Option (sold separately)
P10090-01	Non-cooled		3.65	3.35	TO-5	8	C4159-07 (P.25)
P10090-11	One-stage TE-cooled (Td=-10 °C)	11	3.55	3.30	TO-8		A3179-01 (P.23) C1103-04 (P.22) C4159-06 (P.25)
P10090-21	Two-stage TE-cooled (Td=-30 °C)	φ1	3.45	3.25	10-8		A3179-01 (P.23) C1103-04 (P.22) C4159-06 (P.25)
P7163	Liquid nitrogen (Td=-196 °C)		3.10	3.00	Metal dewar		C4159-05 (P.25)


### InAsSb photovoltaic detectors

This InAsSb photovoltaic detectors deliver high sensitivity in the 5 µm or 8 µm band due to our unique crystal growth technology. (.avT)


0,							(Typ./
Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength (µm)	Package	Photo	Option (sold separately)
P11120-901	Liquid nitrogen (Td=-196 °C)		5.8	4.8	Metal dewar		C4159-01 (P.25)
P11120-201	Two-stage TE-cooled	φ1	5.9	4.9	TO-8		C4159-07 (P.25)
NEW P12691-201	(Td=-30 °C)		8.3	6.7	10-6		C4109-07 (F.25)
NEW P13243-011MA	Non-cooled	0.7 × 0.7	5.3	3.5	TO-46		-

### Spectral response

### InAs photovoltaic detectors



### InAsSb photovoltaic detectors



Wavelength (µm)

KIRDB0356ED

### InSb photovoltaic detectors

InSb photovoltaic detectors are high-speed, low-noise infrared detectors that deliver high sensitivity in the so-called atmospheric window between 3 and 5 µm. The infrared light in the 5 µm band can be detected with peak sensitivity and high response speed. A metal dewar type cooled with liquid nitrogen is also available. (Typ.)

Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
P5968-060		φ0.6					C4159-01 (P.25)
P5968-100		ф1					C4159-01 (F.25)
P5968-200	Liquid nitrogen (Td=-196 °C)	ф2	5.5	5.3	Metal dewar	9	C4159-04 (P.25)
P5968-300		ф3					Custom-made product
P4247-16		0.25 × 1.4 (16-element)					
P4247-44		0.45 × 0.45 (4 × 4-element)					_

### InSb photoconductive detectors


Thermoelectrically cooled InSb photoconductive detectors are capable of detecting infrared light up to around 6 µm with high sensitivity and high speed. (Typ.)

Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
P6606-110	One-stage TE-cooled (Td=-10 °C)	1 1	6.7		TO 0		A3179-01 (P.23) C1103-07 (P.22) C5185-02 (P.26)
P6606-210	Two-stage TE-cooled (Td=-30 °C)	1 × 1	6.5	5.5	TO-8		A3179-01 (P.23) C1103-07 (P.22) C5185-02 (P.26)
P6606-310	Therese	1 × 1					A0170 04 (D00)
P6606-305	Three-stage TE-cooled (Td=-60 °C)	0.5 × 0.5	6.3		TO-3		A3179-04 (P.23) C1103-05 (P.22) C5185-02 (P.26)
P6606-320	- (1u=-00 C)	2 × 2				200	C3103-02 (F.20)


KIRDB0063EE

### Spectral response

### InSb photovoltaic detectors



### InSb photoconductive detectors



KIRDB0166EC

### for Infrared detector modules with preamp


These modules consist of the InSb detector assembled with the matched preamplifier, and operate by connecting a DC power supply. (Typ.)

Type no.	Detector	Photosensitive area (mm)	Cooling	Measurement condition  Element temperature (°C)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Photo
P4631-03	InSb (P6606-310)	1 × 1	TE-cooled	-58	6.1	5.5	
P7751-01* <sup>1</sup>	InSb (P5968-060)	ф0.6	Liquid nitrogen	-196	5.5	5.3	
P7751-02*1	InSb (P5968-200)	ф2	Liquid Illitogell	-130	3.3	3.3	
C12492-210	InAs (P10090-21)	φ1	TE-cooled	-28	3.45	3.25	

<sup>\*1:</sup> FOV=60°

Note: Supplied with a power supply cable

### Spectral response



KIRDB0371EF

# MCT (HgCdTe) photoconductive/photovoltaic detectors

MCT photoconductive detectors decrease their resistance when illuminated by infrared light and are available with various ranges of spectral response up to 22 µm. MCT photovoltaic detectors generate a photocurrent when illuminated by infrared light.

### MCT photoconductive detectors

### Metal package

Non-cooled type and one-stage TE-cooled type have sensitivity up to 10 µm, making them suitable for CO2 laser detection. Two or threestage TE-cooled types deliver high sensitivity in detecting short wavelengths.

							(тур.)
Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
<b>Discontinued</b> P3257-30	Non-cooled		10.0	6.5	With BNC connector		Custom-made product
Discontinued P3257-101	One-stage TE-cooled (Td=0 °C)		10.6	7.0	TO-8		A3179-01 (P.23) C1103-07 (P.22)
<b>Discontinued</b> P3981		1 × 1	4.3	3.6	TO-8		
Discontinued P3981-01	Two-stage TE-cooled (Td=-30 °C)		4.3	3.6	TO-66		A3179-01*2 (P.23) C1103-07 (P.22) C5185-03 (P.26)
<b>Discontinued</b> P2750-08			5.4	4.8	TO-8		
<b>Discontinued</b> P2750	Three-stage	1 × 1		4.0	TO 0		A3179-04 (P.23)
Discontinued P2750-06	TE-cooled (Td=-60 °C)	0.25 × 0.25	5.5	4.8	TO-3		C1103-05 (P.22) C5185-03 (P.26)

<sup>\*2:</sup> For P3981 and P2750-08. The heatsink for the P3981-01 is a custom product.

### Metal dewar type

These include MCT detectors whose peak sensitivity at 10 µm wavelength is suitable for non-contact temperature measurements at room temperature and MCT detectors whose high sensitivity at longer wavelengths (narrow, medium, and wide wavelength bands) makes them suitable for FTIR.


	Type no.	Cooling	Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
Discontinued	P3257-25		0.025 × 0.025					A3515*3 (P.22)
Discontinued	P3257-01		0.1 × 0.1					
Discontinued	P3257-10		1 × 1	12	10		<u> </u>	
Discontinued	1 P4249-08		0.5 × 0.5/ 8-element			Side-on type metal dewar		
Discontinued	P2748-40	Liquid nitrogen (Td=-196 °C)	1 × 1	14	12			A3515 (P.22)
Discontinued	P2748-42		0.25 × 0.25	14	12			C5185-02 (P.26)
Discontinue	P5274		1 × 1	17	14		6	
Discontinued	P5274-01		1 × 1	22	17			
Discontinued	1 P2748-41		1 × 1	14	12	Head-on type metal dewar		

<sup>\*3:</sup> The amplifier for the P3257-25 is available upon request (custom-made product).


### P3257-30/-101

# 10<sup>8</sup> (Typ.) P3257-101 (Td=0 °C) P3257-30 (Td=25 °C) 10<sup>8</sup> P3257-30 (Td=25 °C)

### P3981 series



### P2750 series




### P3257-01/-10/-25, P4249-08


Wavelength (µm)

10 11 12

KIRDB0164EG



### P2748/P5274 series




### **MCT** photovoltaic detectors

(Typ.)

	Type no. Coolii		Photosensitive area (mm)	Cutoff wavelength λc (μm)	Peak sensitivity wavelength λp (μm)	Package	Photo	Option (sold separately)
Discontinued	P9697-01	Liquid nitrogen	φ0.5	13	11	Metal dewar	0	C4159-07 (P.25)
Discontinued	P9697-02	(Td=-196 °C)	φ1	13	11	ivietai üewai	0	C4159-07 (P.25)

### Spectral response



KIRDB0334EC


### for Infrared detector modules with preamp

These modules consist of an MCT detector assembled with a matched preamplifier, and operates by connecting a DC power supply.

_								(тур.)
			Photosensitive		Measurement condition	Cutoff wavelength	Peak sensitivity wavelength	
	Type no.	Detector	area	Cooling	Element temperature	λς	λρ	Photo
			(mm)		(°C)	(µm)	(µm)	
Discontinued	C12495-211S	MCT (P3981)			-25	4.3	3.6	
Discontinued	C12495-311M	MCT (P2750)	1 × 1	TE-cooled	-58	5.5	4.8	
Discontinued	C12495-111L	MCT (P3257-101)			-3	11.5	6.5	
Discontinued	C12495-411V	MCT (P2748-40)		Metal dewar	-196	14	12	J.

Note: Supplied with a power supply cable

### Spectral response



KIRDB0372EG

# Thermopile detectors (Si thermal detectors)

### Single-element type

Hamamatsu provides high-sensitivity thermopile detectors suitable for gas concentration measurement, etc. Concentration of various types of gases can be measured by attaching a band-pass filter to thermopile detectors.

The T11262-06 is suitable for flame detection and the T11361-05 for CO2 concentration measurement.

Type no.	Package	Number of elements	Photosensitive area (mm)	Window	Spectral response (µm)	Photo
T11262-01				AR-coated Si	3 to 5	
NEW T11262-06	TO 10	TO-18 1 1.2 × 1.2		Band-pass filter	-pass filter 4.45	
T11361-01*1	10-18			AR-coated Si	3 to 5	4
NEW T11361-05*1				Band-pass filter	4.3	

<sup>\*1:</sup> Built-in thermistor



### Dual-element type


The T11722-01 is a dual-element type thermopile detector designed to detect CO2 concentrations with a high accuracy. It consists of a high sensitivity dual-element thermopile detector and two band-pass filters for sensing two wavelengths (reference: 3.9 µm, CO2: 4.3 µm) simultaneously.

Type no.	Package	Number of elements	Photosensitive area (mm)	Window	Spectral response (µm)	Photo
T11722-01	TO-5	2	1.2 × 1.2 (per 1 element)	Band-pass filter	Reference: 3.9 CO <sub>2</sub> : 4.3	

### Window options (typical examples of spectral response)

Since thermopile detectors have no wavelength dependence, their spectral response characteristics are determined only by the transmittance of the window material.

The graph below shows transmittance characteristics of typical window materials. Please contact our sales office about changing the window of a thermopile detector to the following materials.



KIRDB0512EA


## **Two-color detectors**


Two-color detectors use a combination of two light sensors with different spectral response, in which one sensor is mounted over the other sensor along the same optical axis to provide a broad spectral response range. Thermoelectrically cooled two-color detectors are also provided that cool the sensors to maintain their temperatures constant, allowing high precision measurement with an improved S/N.


	Type no.	Cooling	Detector	Photosensitive area (mm)	Spectral response range λ (μm)	Peak sensitivity wavelength λp (μm)	Photo sensitivity S (A/W)	Package	Photo	Option (sold separately)
Discontinued	V1712 01		Si	2.4 × 2.4	0.2 to 2.9	0.94	0.45			
Discontinued	1 1713-01		PbS	1.8 × 1.8	0.2 to 2.9	2.2	6 × 10 <sup>4</sup> (V/W)			C9329 C3757-02
Discontinue	K1713-002		Si	2.4 × 2.4	0.2 to 4.8	0.94	0.45			(P.26)
Discontinued	K1713-002		PbSe	1.8 × 1.8	0.2 to 4.0	4.0	$1.5 \times 10^{3} \text{ (V/W)}$			
	K1713-05		Si	2.4 × 2.4	0.32 to 1.7	0.94	0.45			
	K1713-05	Non-cooled	InGaAs	φ0.5	0.32 (0 1.7	1.55	0.55	TO-5		
	K1713-08	-	Si	2.4 × 2.4	0.32 to 2.6	0.94	0.45	10-5		C9329 C4159-03
-	K1713-00		InGaAs	φ1	0.32 10 2.0	2.3	0.60		ide	(P.25)
	K1713-09		Si	2.4 × 2.4	0.00 . 1.7	0.94	0.45			
	K1713-09		InGaAs	φ1	0.32 to 1.7	1.55	0.55			
	V11000 010V		InGaAs	2.4 × 2.4	0.9 to 2.55	1.55	0.95			C4159-03
	K11908-010K		InGaAs	φ1	0.9 (0 2.55	2.1	1.0			(P.25)
Discontinued	V2412 01	112.01	Si	2.4 × 2.4	0.2 to 3.1	0.94	0.45			C9329
Discontinued	K3413-01		PbS	1.8 × 1.8	0.2 to 3.1	2.4	3 × 10 <sup>5</sup> (V/W)			C3757-02 (P.26)
			Si	2.4 × 2.4		0.94	0.45			A3179-03 (P.23)
Discontinued	K3413-002	One-stage	PbSe	1.8 × 1.8	0.2 to 5.1	4.1	4.5 × 10 <sup>3</sup> (V/W)			C1103-04 (P.22)
	K3413-05	TE-cooled	Si	2.4 × 2.4	0.32 to 1.67	0.94	0.45	TO-8		
	K3413-05	(Td=-10 °C)	InGaAs	φ0.5	0.32 to 1.07	1.55	0.55			C9329 C4159-03
	K3413-08		Si	2.4 × 2.4	0.32 to 2.57	0.94	0.45		1001	(P.25) A3179-03
	K3413-06		InGaAs	φ1	0.32 10 2.37	2.3	0.60		5.113	(P.23)
-	K3413-09		Si	2.4 × 2.4	0.32 to 1.67	0.94	0.45			C1103-04 (P.22)
	N3413-09		InGaAs	φ1	0.32 (0 1.67	1.55	0.55			(1.22)
_	V40700 040K		Si	2.4 × 2.4	0.22 to 1.65	0.96	0.45			
	NEW K12728-010K	Non cools -	InGaAs	φ1	0.32 to 1.65	1.55	0.55	Caranis	الميا	_
-	V40700 040K	Non-cooled	InGaAs	2.4 × 2.4	0.0+0.2 FF	1.55	0.95	Ceramic	ic	
_	NEW K12729-010K		InGaAs	φ1	0.9 to 2.55	2.1	1.0		الميدا	

### Spectral response

### K1713-01/-002, K3413-01/-002









### K1713-05/-08/-09

### [ Si photodiode ]




### [InGaAs PIN photodiode]



KIRDB0211EA


### K3413-05/-08/-09

[Si photodiode]




KIRDB0199EA

### [InGaAs PIN photodiode]




KIRDB0212EA

### K11908-010K, K12729-010K



### K12728-010K



KIRDB0598EB

# Photon drag detector

The photon drag detector makes use of the "photon drag effect" in which holes created in a semiconductor by incident photons are dragged along in the direction of the photons, generating an electromotive force. Because of its sensitivity at 10.6  $\mu$ m, this detector is suitable for detection of CO<sub>2</sub> lasers. The surface of the detector element is coated with a non-reflective material.

### Non-cooled type

φ30 ± 1

(Typ.)


Type no.	Cooling	Photosensitive area	Peak sensitivity wavelength λp (μm)	Photosensitivity S λ=10.6 μm (V/W)	Photo	Magnet stand (sold separately)
B749	Non-cooled	φ5.0	10.6	1.2 × 10 <sup>-6</sup>		A1447

### Dimensional outlines (unit: mm, tolerance unless otherwise noted: ±1)

B749

# 79.5 ± 2 RNC connector

### Magnet stand A1447




# **Accessories for infrared detectors**

HAMAMATSU provides following accessories for infrared detectors.

- · Temperature controllers (P.22)
- · Heatsinks for TE-cooled detector (P.23)
- · Chopper (P.24)
- · Amplifiers for infrared detectors (P.25)

A connection example is shown below.

### Connection example



Cable no.	Cable	Length approx.	Note
1	Coaxial cable (for signal)	2 m	Supplied with heatsink A3179 series. When using this cable, make it as short as possible (preferably approx. 10 cm).
2	4-conductor cable (with a connector) A4372-05	3 m	Supplied with temperature controller C1103 series. This cable is also sold separately.
3	Power supply cable (with a 4-conductor connector) A4372-02	2 m	This cable is supplied with the C4159/C5185 series amplifiers for infrared detectors, the C3757-02, and infrared detector modules with preamps (room temperature type).  This cable is also sold separately. Besides this cable, the A4372-03, which is a power supply cable (with a 6-conductor connector) supplied with "infrared detector modules with preamps (cooled type)", is also sold separately.
4	BNC connector cable E2573	1 m	Option
(5)	Power supply cable (for temperature controller)	1.9 m	Supplied with temperature controller C1103 series
<u> </u>	Chopper driver cable (connected to chopper)	2 m	Connected to chopper driver circuit
7	2-conductor cable or coaxial cable (for chopper power supply)	2 m or less	Prepared by user

<sup>\*1:</sup> Attach the bare wire ends to a 3-pin or 4-pin connector or to a banana jack, and then connect them to the power supply.
\*2: Soldering is needed. When using the C5185 series amplifier, a BNC connector (prepared by the user, example: one end of the E2573) is required.
\*3: No socket is available. Soldering is needed.

Note: Refer to the datasheet "Accessories for infrared detectors" for detailed information about cables

### Temperature controllers C1103 series


The C1103 series is a temperature controller designed for TE-cooled infrared detectors. The C1103 series allows temperature setting for the TE-cooler mounted in an infrared detector.

### **Specifications**

Parameter	C1103-04	C1103-05	C1103-07	
Applicable detector*4	One-stage/two-stage TE-cooled type PbS, PbSe photoconductive detectors, InAs photovoltaic detectors, InGaAs, Si photodiodes  InGaAs, Si photodiodes		One-stage TE-cooled type MCT, InSb photoconductive detectors	
Setting element temperature	-30 to +20 °C	-75 to -25 °C	-30 to +20 °C	
Temperature stability		Within ±0.1 °C		
Temperature control output current	1.1 A min., 1.2 A typ., 1.3 A max.			
Power supply	100 V ± 10% · 50/60 Hz*5			
Power consumption	30 W			
Dimensions	107 (W) × 87 (H) × 190 (D) mm			
Weight		Approx. 1.9 kg		
Operating temperature	+10 to +40 °C			
Operating humidity	90% max.			
Storage temperature*6	-20 to +40 °C			
Accessories	Instruction manual 4-conductor cable (with a connector, 3 m) A4372-05*7, power supply cable			

<sup>\*4:</sup> It does not correspond to TE-cooled type infrared detector module with preamp.

### Block diagram




### Valve operator for metal dewar A3515

With this valve operator, metal dewars can be re-evacuated to maintain the desired vacuum level. Refer to the instruction manual for details. Please be aware that the detector performance is not guaranteed after re-evacuation is performed with the valve operator.

Vaccum pump Valve operator Metal dewar type detector

### Dimensional outline (unit: mm)



KIRDA0021EC

<sup>\*5:</sup> Please specify power supply requirement (AC line voltage) from among 100 V, 115 V and 230 V when ordering

<sup>\*6:</sup> No condensation

<sup>\*7:</sup> When used in combination with the A3179 series heatsink, do not use the 4-conductor cable supplied with the A3179 series, but use the A4372-05 instead.

### Heatsinks for TE-cooled detectors (TO-8, TO-3 package) A3179 series

These heatsinks are designed for use with thermoelectrically cooled detector sealed in a 6-pin TO-8, TO-3 package. The cooling (heat dissipation) capacity of the A3179 and A3179-03 is approx. 35 °C relative to the ambient temperature 25 °C, the A3179-01 is approx. 40 °C, and that of the A3179-04 is approx. 85 °C. The A3179-03 is designed only for two-color detector K3413 series, the A3179 for one-stage TE-cooled TO-8, the A3179-01 for two-stage TE-cooled TO-8, the A3179-04 for TO-3 (heatsink for TO-66 is available as a custom product.).

Accessories

- Instruction manual 4-conductor cable (2 m): for TE-cooler and thermistor\*1 \*2
- Coaxial cable (2 m): for signal\*2
- \*1: When used in combination with the C1103 series temperature controller, do not use the 4-conductor cable supplied with the A3179 series, but use the 4-conductor cable A4372-05 (sold separately, with a connector) that comes with the C1103 series
- \*2: No socket is supplied for connection to infrared detectors. Connect infrared detectors by soldering. Cover the soldered joints and detector pins with vinyl insulating tubes.


### Dimensional outlines (unit: mm, tolerance unless otherwise noted: ±0.3)

# A3179 Photosensitive surface\*3 $0.4 \pm 0.3^{+2}$ (4 ×) ø 3.5 Weight: approx. 50 g


- \*1: Bottom surface (reference surface) of detector metal package \*2: When the detector is installed \*3: The position of the photosensitive surface differs according to the detector used Refer to the dimensional outline for the detector

KIRDA0018EE

### A3179-01, A3179-03



- \*1: Bottom surface (reference surface) of detector metal package \*2: When detector is installed \*3: The position of the photosensitive surface differs according to the detector used. Refer to the dimensional outline for the detector.



KIRDA0149EC

### Chopper C4696


### **Specifications**


Parameter		Specification
Chopping frequency		115 to 380 Hz, 345 Hz typ.* <sup>3</sup>
Operating voltage VD		DC 5 to 13 V, 12 V typ.
Duty ratio		1:1
Rotational stability		0.06%/°C
Sync signal Vн (high level)	Min.	V <sub>D</sub> - 0.5 V
	Max.	V <sub>D</sub> - 0.2 V
Operating temperature		0 to 50 °C
Maximum current consumption*4		90 mA
Accessories		Magnet stand A1447 (see P.20), driver circuit


<sup>\*3:</sup> Chopping frequency will be 230 to 760 Hz when an optional disk is used.

### Dimensional outline (unit: mm, tolerance unless otherwise noted: ±1)

### Chopping frequency vs. operating voltage







KIRDA0022EA

<sup>\*4:</sup> VD=12 V

### Amplifiers for infrared detectors C4159/C5185 series, C3757-02

These are low noise amplifiers for InSb, InAs, InAsSb, InGaAs, MCT, PbS and PbSe detectors

Accessories

■ Instruction manual ■ Power cable (one end with 4-pin connector for connection to amplifier and the other end unterminated, 2 m) A4372-02

### Required power supply specifications

C4159 series: ±15 V ± 0.5 C5185 series: ±15 V ± 0.5

- · Current capacity: 1.5 times or more of amplifier's maximum current consumption
- Ripple noise: 5 mVp-p or less
- Analog power supply only

Recommended DC power supply (example): E3620A, E3630A

(Agilent Technologies)



### Absolute maximum ratings (Ta=25 °C)

Parameter	Value	Unit
Operating temperature	0 to +40	°C
Storage temperature	-20 to +70	°C

### Amplifiers for photovoltaic detectors (Typ.)

Parameter	C4159-01	C4159-04	C4159-05	C4159-06	C4159-07	Unit
Applicable detector*1 *2 *3	Dewar type InSb (P5968-060, P5968-100) Dewar type InAsSb (P11120-201)	Dewar type InSb (P5968-200)	Dewar type InAs (P7163)	TE-cooled type InAs (P10090-11/-21)	Non-cooled type InAs (P10090-01) TE-cooled type InAsSb (P11120-201, P12691-201) Dewar type MCT	-
Conversion impedance	10 <sup>8</sup> , 10 <sup>7</sup> , 10 <sup>6</sup> (3 ranges switchable)	$2 \times 10^{7}$ , $2 \times 10^{6}$ , $2 \times 10^{5}$ (3 ranges switchable)	10 <sup>8</sup> , 10 <sup>7</sup> , 10 <sup>6</sup> (3 ranges switchable)	- ,	0 <sup>5</sup> , 10 <sup>4</sup> switchable)	V/A
Frequency response (amp only, -3 dB)	DC to 100 kHz*4 DC to 45 kHz DC to 15 kHz DC to 100 kHz		-			
Output impedance	50			Ω		
Maximum output voltage (1 $k\Omega$ load)	+10					V
Output offset voltage	±5	±5 ±5 ±10 ±5		±5	mV	
Equivalent input noise current*5 (f=1 kHz)	0.15 (10 <sup>8</sup> , 10 <sup>7</sup> range) 0.65 (10 <sup>6</sup> range)	0.55	0.15 (10 <sup>8</sup> , 10 <sup>7</sup> range) 0.65 (10 <sup>6</sup> range)	6	10	pA/Hz <sup>1/2</sup>
Reverse voltage	Limited to 0 V operation				-	
External power supply*6	±15				V	
Current consumption	+30, -10 max. +30, -22 max.			22 max.	mA	

### Amplifiers for InGaAs PIN photodiodes (Typ.)

Parameter	C4159-03	Unit
Applicable detector*1 *2	InGaAs	-
Conversion impedance	10 <sup>7</sup> , 10 <sup>6</sup> , 10 <sup>5</sup> (3 ranges switchable)	V/A
Frequency response (amp only, -3 dB)	DC to 15 kHz	-
Output impedance	50	Ω
Maximum output voltage (1 kΩ load)	+10	V
Output offset voltage	±5	mV
Equivalent input noise current (f=1 kHz)	2.5	pA/Hz <sup>1/2</sup>
Reverse voltage	Can be applied from external unit	-
External power supply*5	±15	V
Current consumption	±15 max.	mA

Note: Output noise voltage = Equivalent input noise current × Conversion impedance

- \*1: These amplifiers cannot operate multiple detectors.
- \*2: Consult us before purchasing if you want to use with a detector other than listed here.
  \*3: Consult us before purchasing if you want to use with a multi-element detector.

 The Recommended DC power supply (analog power supply): ±15 V
 Current capacity: More than 1.5 times the maximum current consumption Ripple noise: 5 mVp-p or less



<sup>\*4:</sup> When connected to a detector, frequency response becomes 60 kHz or less depending on the detector photosensitive area. (\phi0.6 mm: 60 kHz or less, \phi1 mm: 25 kHz or less) Ringing occurs in the output if the rise time tr (0 to 90%) of incident light is approximately 100 \(\mu\)s or less. The ringing becomes larger as the rise time becomes shorter. No ringing occurs when detecting sine-wave light. (For information on the ringing specifications, refer to the datasheet "Amplifier for infrared detector".) \*5: Input resistance:  $1 \text{ M}\Omega$  (C4159-01/-04/-05), 500  $\Omega$  (C4159-06/-07)

### Accessories for infrared detectors

### ■ Amplifiers for photoconductive detectors (Typ.)\*<sup>7</sup>

7 tillpilliore for priotecon	4401110 401001010 (1)	Discontinued	Discontinued	
Parameter	C5185-02	C5185-03	C3757-02	Unit
Applicable detector*8 *9 *10	Dewar type MCT, InSb (P6606 series)	MCT (P3981/P2750 series)* <sup>11</sup>	PbS, PbSe	-
Input impedance	5	5	10000	kΩ
Voltage gain	66 (× 2000)	66 (× 2000)	40 (× 100)	dB
Frequency response (amp only, -3 dB)	5 Hz to 250 kHz	5 Hz to 250 kHz	0.2 Hz to 10 kHz	-
Detector bias current 5 mA, 10 mA, 15 m (3 ranges switchab		0.1 mA, 0.5 mA, 1 mA (3 ranges switchable)	Internal bias	-
Output impedance		50		Ω
Maximum output voltage (1 kΩ load)		±10		V
Equivalent input noise voltage (f=1 kHz)	out noise voltage (f=1 kHz) 2.6		40	nV/Hz <sup>1/2</sup>
External power supply*12		±15		V
Current consumption	+100, -30 max.	+100, -30 max.	+15, -15 max.	mA

Note: Output noise voltage = Equivalent input noise voltage  $\times$  Voltage gain

- \*7: Before purchasing, make sure the bias current to the detector matches the detector bias current specified in the above table.

\*7: Before purchasing, make sure the bias current to the detector matches the detector bia?
\*8: These amplifiers cannot operate multiple detectors.
\*9: Consult us before purchasing if you want to use with a detector other than listed here.
\*10: Consult us before purchasing if you want to use with a multi-element detector.
\*11: Preamp for P3257-25/-30/-101 available upon request
\*12: Recommended DC power supply (analog power supply): ±15 V
Current capacity: More than 1.5 times the maximum current consumption Ripple noise: 5 mVp-p or less

### Dimensional outlines (unit: mm, tolerance unless otherwise noted: ±1)


### C4159-01/-03/-04/-05/-06/-07

### 4-pin connector 12.5 PREAMPLIFIER 24.5 9 LOUT HAMAMATSU Gain adjusting screw Offset voltage BNC connector adjusting screw 85 Solder leads to these terminals. Pin connections

Note: Socket for lead attachment is not provided.

① GND ② Cathode 3 Anode

### C3757-02




Pin connections

- ① GND
- ② Detector
- ③ Detector

Note: Socket for lead attachment is not provided.

KIRDA0049EC

### C5185-02/-03



KIRDA0046EC

# **Description of terms**

### Dark resistance: Rd

This is the resistance of a photoconductive detector (PbS, PbSe, MCT, etc.) in the dark state.

### Dark current: ID

The dark current is the small current which flows when a reverse voltage is applied to a photovoltaic detector (InGaAs, InAs, InSb, etc.) under dark conditions. This is a factor for determining the lower limit of light detection.

### FOV (field of view)

The field of view is related to the background radiation noise and greatly influences the value of D\*.

### Offset voltage

This is DC output voltage of an amplifier when the input signal is zero.

### Photosensitivity: S

This is the detector output per watt of incident light at a given wavelength. The unit is usually expressed in V/W for photoconductive and in A/W for photovoltaic detectors. For photon drag detectors, this is represented as the output voltage with respect to incident pulsed energy of 1 kW radiated from a CO<sub>2</sub> laser.

### Photovoltaic detector (photodiode)

This is a semiconductor detector that generates electrical current or voltage when light enters its PN junction. Detector materials include InGaAs, InAs, InAsSb, InSb, and MCT (HgCdTe).

### Photoconductive detector

This is a semiconductor detector whose conductivity increases with increasing incident light. Detector materials include PbS, PbSe, InSb and MCT (HgCdTe).

### • Peak sensitivity wavelength: λp

This is the wavelength at which the sensitivity of the detector is at maximum

### Reverse voltage (max.): VR max, supply voltage

Applying a reverse voltage to a photovoltaic detector (or applying a voltage to a photoconductive detector) triggers a breakdown at a certain voltage and causes severe deterioration of the detector performance. Therefore the absolute maximum rating for the voltage is specified at the voltage somewhat lower than this breakdown voltage. Do not apply a voltage higher than the maximum rating.

### Allowable current (max.)

This is a maximum value of current which can be used when photoconductive detectors are operated. When the supply current is higher than the maximum allowable current, the detector performance may deteriorate, therefore, excessive current must be avoided.

### NEP (noise equivalent power)

This is the radiant power that produces S/N of 1 at the detector output. At HAMAMATSU we list the NEP measured at the peak sensitivity wavelength ( $\lambda p$ ). Since the noise level is proportional to the square root of the frequency bandwidth, the NEP is normalized to a bandwidth of 1 Hz.

NEP [W/Hz<sup>1/2</sup>] = 
$$\frac{\text{Noise current [A/Hz^{1/2}]}}{\text{Photosensitivity [A/W] at } \lambda p}$$

### Cutoff frequency: fc

This is the frequency at which the output decreases 3 dB from the steady output level. The cutoff frequency (fc) is related to rise time (tr: time required for the output to rise from 10% to 90% of the maximum output value) as follows:

$$tr[s] = \frac{0.35}{fc[Hz]}$$

### Rise time: tr

This is the value of a detector time response to a stepped light input, and defined as the time required for transition from 10% to 90% (or 0 to 63%) of the maximum (constant) output value. The light sources used are GaAs LED (0.92  $\mu$ m), laser diode (1.3  $\mu$ m), etc.

### Terminal capacitance: Ct

An effective capacitor is formed at the PN junction of a photovoltaic detector. Its capacitance is termed the junction capacitance and is one of the parameters that determine the response speed of the photovoltaic detector. And it can cause the phenomenon of gain peaking in I-V conversion circuit using op amp. In HAMAMATSU, the terminal capacitance including this junction capacitance plus package stray capacitance is listed.

### Short circuit current: Isc

The short circuit current is the output current which flows when the load resistance is 0 and is nearly proportional to the device photosensitive area. This is often called "white light sensitivity" with regards to the spectral response. This value is measured with light from a tungsten lamp of 2856 K distribution temperature (color temperature), providing 100 *lx* illuminance.

### • Cutoff wavelength: λc

This represents the long wavelength limit of spectral response and in datasheets is listed as the wavelength at which the sensitivity becomes 10% of the value at the peak sensitivity wavelength.

### Chopping frequency

In the measurement of infrared detector sensitivity, an optical chopper is often used to perform on-off operation of incident light. This is the frequency of the chopper.

### D\* (D-star: Detectivity)

 $D^{\ast}$  is the detectivity indicating the S/N in an AC signal obtained by a detector when radiant energy of 1 W is input to the detector.  $D^{\ast}$  is normalized to a detector area of 1 cm² and a noise bandwidth of 1 Hz, to allow comparing of characteristics of detector materials independent of the detector area.  $D^{\ast}$  is usually represented as  $D^{\ast}$  (A, B, C), in which A is the light source temperature [K] or wavelength [μm], B is the chopping frequency [Hz], and C is the noise bandwidth [Hz].  $D^{\ast}$  is expressed in units of cm  $\cdot$  Hz¹/²/W, and the higher the  $D^{\ast}$ , the better the detector.  $D^{\ast}$  is given by the following equation.

$$D^* = \frac{S/N \cdot \Delta f^{1/2}}{P \cdot A^{1/2}}$$

where S is the signal, N is the noise, P is the incident energy in [W/cm²], A is the photosensitive area in [cm²] and  $\Delta f$  is the noise bandwidth in [Hz]. The following relation is established by D\* and NEP.

$$D^* = \frac{A^{1/2}}{NEP}$$

### Noise: N

The noise is the output voltage from a photoconductive detector operated under specified conditions and 300 K background radiations.

### Shunt resistance: Rsh

This shunt resistance is the voltage-to-current ratio in the vicinity of 0 V in photovoltaic detectors and defined as follows: Where ID is the dark current at reverse voltage=10 mV.

$$Rsh [\Omega] = \frac{10 [mV]}{ID [A]}$$

For applications where no reverse voltage is applied, noise resulting from the shunt resistance becomes predominant.

### Quantum efficiency: QE

The quantum efficiency is the number of electrons or holes that can be detected as a photocurrent, divided by the number of incident photons. This is commonly expressed in percent [%]. The quantum efficiency and photosensitivity S have the following relationship at a given wavelength [nm]:

$$QE = \frac{S \times 1240}{\lambda} \times 100 \text{ [\%]}$$



Date.
No.



Date.
No.

### Disclaimer

- •Products manufactured by Hamamatsu Photonics K.K. (hereafter "Hamamatsu") are intended for use in general-use electronic devices (such as measurement equipment, office equipment, information communications equipment, household appliances, etc.). Unless an exception to the following is stated in the documentation of a specific product, Hamamatsu products are not to be used for special applications which demand extremely high reliability or safety (such as equipment for nuclear power control, aerospace equipment, medical equipment and transportation equipment that directly affect human life, or disaster prevention or safety equipment).
- Hamamatsu products should not be used in excess of their absolute maximum ratings. Attention must be paid to all documented precautions.
- •Hamamatsu continually makes efforts to improve the quality and reliability of its products; however these efforts cannot ensure 100% compliance with the manufacturing specifications. Sufficient safety design (such as redundant safety, fire preventative, and malfunction preventative features) are to be implemented in the development of equipment manufactured with the Hamamatsu product so that personal injury, fire, or damage to public property or welfare does not occur in the unlikely event of a malfunction of the Hamamatsu product. A dangerous condition could be created if sufficient consideration is not given to safety design that addresses potential problems, especially in the design of equipment where the failure or malfunction of the Hamamatsu product within the equipment could result in bodily harm, life-threatening injury, or serious property damage during the use of the equipment. With such types of equipment, Hamamatsu shall not be responsible for the use of its products within the equipment in any way for not obtaining our written consent such as specification sheets beforehand.
- •Appropriate descriptions of the functions, performance, and methods of operation of the Hamamatsu product and the equipment within which the Hamamatsu product is incorporated are to be provided to end-users of the equipment. All accompanying warnings and cautionary labeling are also to be provided to the end-user.
- •Warranty of the Hamamatsu product is limited to the repair or replacement of a product in which a defect is discovered within 1 year of delivery of the product and notification is made to Hamamatsu within that period, otherwise certain warranty is specified. However, even within the warranty period Hamamatsu shall not be responsible for damages caused by either natural disaster or improper use of the product (such as modification of the product or any use that contravenes the operating conditions, intended applications, operating instructions, storage method, disposal method, or any other term or condition described in our products' documents). For a complete description of the warranty associated with a particular product, please contact your regional Hamamatsu sales office.
- •Exportation of some Hamamatsu products must comply with individual governmental regulations pertaining to export control. Export in contravention of governmental regulations is a crime and can result in severe monetary penalties or imprisonment. While we cannot give any legal advice as to how to comply with these regulations, we can help classify the goods in order to assist the buyer in determining what regulations apply. Please contact your regional Hamamatsu sales office for further assistance.
- •In our products' documents, applications are mentioned as notable examples of how the Hamamatsu product can be used. Such mentions guarantee neither the suitability of the product for specific purposes nor the success or failure of the commercial use of the product in specific applications. Some applications may be protected by patents or other proprietary rights. Hamamatsu assumes no liability for any infringing use of our products. All warranties express or implied, including any warranty of merchantability or fitness for any particular purpose are hereby excluded.
- •Product specifications are subject to change without notification due to product improvements, etc. Our products' documents have been carefully prepared to ensure the accuracy of the technical information contained herein, but in rare cases there may be errors. When using the Hamamatsu product, please be sure to request the delivery specification sheets, and confirm upon delivery that it is the most recent specifications. In addition to this document, please be sure to read any accompanying technical documentation and make note of any precautions listed in the delivery specification sheets.
- •All Rights Reserved, transfer or duplication of the contents of our products' documents without the permission of Hamamatsu is prohibited.

# AMAMATSL

### HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1, Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558, Japan Telephone: (81)53-434-3311, Fax: (81)53-434-5184

www.hamamatsu.com

### **Main Products**

Si photodiodes

APD

**MPPC** 

Photo IC

Image sensors

**PSD** 

Infrared detectors

**LED** 

Optical communication devices

Automotive devices

X-ray flat panel sensors

Mini-spectrometers

Opto-semiconductor modules

### Hamamatsu also supplies:

Photoelectric tubes Imaging tubes Light sources Imaging and processing systems

Information in this catalogue is believed to be reliable. However. no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein.

© 2015 Hamamatsu Photonics K.K.

Quality, technology, and service are part of every product.

### Sales Offices

### Japan:

### HAMAMATSU PHOTONICS K.K.

325-6, Sunayama-cho, Naka-ku, Hamamatsu City, Shizuoka Pref. 430-8587, Japan Telephone: (81)53-452-2141, Fax: (81)53-456-7889 E-mail: intl-div@hq.hpk.co.jp

### China:

### HAMAMATSU PHOTONICS (CHINA) Co., Ltd.

Main Office

1201 Tower B, Jiaming Center, 27 Dongsanhuan Beilu, Chaoyang District, 100020 Beijing, China Telephone: (86)10-6586-6006, Fax: (86)10-6586-2866 E-mail: hpc@hamamatsu.com.cn

### Shanghai Branch

4905 Wheelock Square, 1717 Nanjing Road West, Jingan District, 200040 Shanghai, China

Telephone: (86)21-6089-7018, Fax: (86)21-6089-7017

### USA .

### HAMAMATSU CORPORATION

Main Office

360 Foothill Road, Bridgewater, NJ 08807, U.S.A. Telephone: (1)908-231-0960, Fax: (1)908-231-1218 E-mail: usa@hamamatsu.com

### California Office

2875 Moorpark Ave. San Jose, CA 95128, U.S.A. Telephone: (1)408-261-2022, Fax: (1)408-261-2522 E-mail: usa@hamamatsu.com

### Chicago Office

4711 Golf Road, Suite 805, Skokie, IL 60076, U.S.A. Telephone: (1)847-725-6046, Fax: (1)847-825-2189 E-mail: usa@hamamatsu.com

### Boston Office

20 Park Plaza, Suite 312, Boston, MA 02116, U.S.A. Telephone: (1)617-536-9900, Fax: (1)408-261-2522 E-mail: usa@hamamatsu.com

# United Kingdom: HAMAMATSU PHOTONICS UK Limited

Main Office

2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, UK
Telephone: (44)1707-294888, Fax: (44)1707-325777 E-mail: info@hamamatsu.co.uk

### South Africa Office:

PO Box 1112, Buccleuch 2066, Johannesburg, South Africa

Telephone/Fax: (27)11-802-5505

# France, Portugal, Belgium, Switzerland, Spain: HAMAMATSU PHOTONICS FRANCE S.A.R.L.

Main Office

19, Rue du Saule Trapu Parc du Moulin de Massy, 91882 Massy Cedex, France Telephone: (33)1 69 53 71 00 Fax: (33)1 69 53 71 10

E-mail: infos@hamamatsu.fr

### Swiss Office

Dornacherplatz 7 4500 Solothurn, Switzerland Telephone: (41)32-625-60-60, Fax: (41)32-625-60-61 E-mail: swiss@hamamatsu.ch





### Belgian Office

Axisparc Technology, rue Andre Dumont 7 1435 Mont-Saint-Guibert, Belgium Telephone: (32)10 45 63 34 Fax: (32)10 45 63 67 E-mail: info@hamamatsu.be

### Spanish Office

C. Argenters, 4 edif 2 Parque Tecnológico del Vallés 08290 Cerdanyola (Barcelona), Spain Telephone: (34)93 582 44 30 Fax: (34)93 582 44 31

E-mail: infospain@hamamatsu.es

### Germany, Denmark, The Netherlands, Poland: HAMAMATSU PHOTONICS DEUTSCHLAND GmbH.

Main Office

Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany

Telephone: (49)8152-375-0, Fax: (49)8152-265-8 F-mail: info@hamamatsu de

### Danish Office

Lautruphøj 1-3, DK-2750 Ballerup, Denmark Telephone: (45)70-20-93-69, Fax: (45)44-20-99-10 Email: info@hamamatsu.dk

### Netherlands Office

Televisieweg 2, NL-1322 AC Almere, The Netherlands Telephone: (31)36-5405384, Fax: (31)36-5244948 E-mail: info@hamamatsu.nl

### Poland Office

02-525 Warsaw, 8 St. A. Boboli Str., Poland Telephone: (48)22-646-0016, Fax: (48)22-646-0018 E-mail: poland@hamamatsu.de

### North Europe and CIS:

### HAMAMATSU PHOTONICS NORDEN AB

Main Office

Torshamnsgatan 35 16440 Kista, Sweden Telephone: (46)8-509 031 00, Fax: (46)8-509 031 01 E-mail: info@hamamatsu.se

### Russian Office

11, Christoprudny Boulevard, Building 1, Office 114, 101000, Moscow, Russia Telephone: (7)495 258 85 18, Fax: (7)495 258 85 19 E-mail: info@hamamatsu.ru

### Italy:

### HAMAMATSU PHOTONICS ITALIA S.r.I.

Main Office

Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy Telephone: (39)02-935-81-733, Fax: (39)02-935-81-741 E-mail: info@hamamatsu.it

### Rome Office

Viale Cesare Pavese, 435, 00144 Roma, Italy Telephone: (39)06-50513454, Fax: (39)06-50513460 E-mail: inforoma@hamamatsu.it